



Body tube (ET-20) Α (BC-20) В Nose cone (BAL10007) C Balsa (LUG125) Launch lug D (Dowel10007) Ε Dowel (3) F Decal* (D10007) (TEM10007) Template* G *Items not shown





Apply white glue inside the end of the body tube. Insert the nose cone so it touches the glue and put aside to dry.

2




Cut and lightly sand the balsa fins with fine sandpaper.

3



Cut out the fin marking guide and wrap it around the body tube. Mark the fin and launch lug locations with a pencil.

4



Glue the three fins to the fin location marks, one at a time, with white glue, to the body tube. Wait for all the fins to dry throughly.

